



KITCHEN EQUIPMENT CLEANING & DEGREASING TABLETS

This innovative and effective alkaline tablet is a powerful and concentrated cleaning solution designed to effectively clean fryers, frying tables, commercial combi ovens with built-in cleaning function, dishwashers, tanks, and closed systems commonly found in kitchens. It can remove grease, oil, dirt, and discolored coatings with ease.



Effective for fryers, frying tables, commercial combi ovens with dishwashers, tanks and closed systems in kitchens.

+ SAFE


+ POWERFUL

+ EFFECTIVE

This product complies with food legislation, ensuring it is safe to use in the food industry without compromising the safety and hygiene of the food. It does not release any toxic substances that could potentially harm human health.



AVAILABLE IN BOXES OF 40 OR 110 TABLETS
Each 35g tablet yields 5-10L of cleaning solution.



FEATURES

- Efficient cleaning
- Removes grease, oil and dirt
- Improves lifetime and performance
- Low foaming
- No Microplastics
- Natural and Organic light biodegradable ingredients
- Low CVD value (Critical Dilution Value)
- Good Manufacturing Practice (GMP) Certified

JUST ADD WATER

To activate the power of a tablet simply add water and dissolve

xerotabs.com

STORAGE:

Store in tightly closed original packaging and in accordance with applicable regulations in a dry and cool place protected against humidity. Keep separate from food, animal feed and similar.

Maximum storage time: 24 months in closed original packaging.



EFFICIENT CLEANING

Removes grease and dirt



ECO FRIENDLY CLEANING

Biodegradable and low CO2 footprint



CLEANING IN PLACE

Just add water

xerotabs



DIRECTIONS FOR USE AND DILUTION

	<ul style="list-style-type: none"> • Use 1-2 tablets depending on the degree of soiling. • Dissolve the tablet on the frying table in warm water. Turn on some heat on the table. Leave to work for about 30 min before pouring off.
	<ul style="list-style-type: none"> • Use 1-2 tablets depending on the degree of soiling. • Dissolve the tablet in the fryer in warm water. Turn on some heat on the fryer. Leave to work for about 30 min before flushing out.
	<ul style="list-style-type: none"> • Use 1-2 tablets depending on the degree of soiling. • Place the tablet in the oven's cleaning compartment or inside the oven next to the fan, follow the instructions on the display.
	<ul style="list-style-type: none"> • Place the tablet on the bottom of the empty dishwasher. Run a complete program with hot water setting.

DISCOVER XEROTABS

The revolutionary cleaning tablets that dissolve in water, providing a potent and affordable clean, without relying on harsh chemicals or expensive shipping. Made with 100% natural ingredients, Xerotabs help you significantly reduce cleaning expenses, while also minimizing your carbon footprint. Simple to use and store, Xerotabs are the ultimate cleaning solution for any business seeking a more sustainable approach to cleaning. Join us in the quest for a greener future and experience the power of Xerotabs today.

LESS ENVIRONMENTAL IMPACT LIQUID DETERGENT vs TABLETS

Transport and packaging of 100 x 200-liter barrel = 1860 kg CO₂



The same as 400 x 4kg cartoons with tablets = 75 kg CO₂.



Tablets → reduced environmental impact of CO₂ with 95,9%!

